

















Partition 1




Partition 2




Partition 3




Partition 4




Partition 5




Partition 6




Partition 7




Partition 8



Partition 9



Partition 10



Partition 11

- Notes:**
- Freestanding
 - 18' View Wall Starts - In place of Top Guide for Partitions 10 & 11
 - 10' View Guide - Floor Guide for Partitions 10 & 11
 - 10' View Track - Floor/Ceiling Track for Partitions 10 & 11
 - 10' View Wallstarts - Vertical Wall Starts for Partitions 10 & 11
 - 10' View Freestanding Support Post - Verticals at Sliding Door for Partition 10
 - 3-Form Panel - 10" Panels in View.
 - 12' Flex Track - Floor/Ceiling Track for Partitions 5,6,8(right side)
 - Floor Track for Partition 2
 - 8' Flex Track - Floor/Ceiling Track for Partitions 1,3,4,7,8(left side), 9
 - Ceiling Track for Partition 2
 - 9' Flex Studs - Verticals
 - 3'2" Flex Studs - Horizontals above Door Headers
 - 4' Support Studs - Needed for TV Mounts. Confirm Location on site

View = 3/8" Single Pane Glass
 Flex = 1/4" Double Pane Glass
 Aluminum Doors = 1/4" Double Pane Glass
 *4 Hinges Per Door